

# Cooling Water Filter



## ● Use

Attached to the inlet of Jet Cool System, or Water Softener, it removes dirt, sand, slime etc. to prevent clogging of the cooling water channels.

## ● Specification

| Type                 |           | JPF - AT  | JPF              | JJF              |
|----------------------|-----------|---|------------------|------------------|
| Cleaning method      |           | Automatic cleaning with timer setting.                    | Manual Operation | Manual Operation |
| Element Mesh Width   |           | 100 μm (Supplied upon order for 500 μm, 320 μm and 30 μm) |                  |                  |
| Max. Flow Rate (ℓ/h) | Tube Dia. | 20A 3/4"  | 4,000            | 3,300            |
|                      |           | 25A 1"  | 4,500            | 4,500            |
|                      |           | 32A 1 1/4"  | 5,500            | 5,500            |
|                      |           | 40A 1 1/2"  | 16,000           | 16,000           |
|                      |           | 50A 2"  | 17,000           | 17,000           |
| Power                |           | AC220V Single Phase                                       | -----            | -----            |

## ● Example of order code designation

Model — Tube Dia  
**JPF-AT — 32A**

※Please designate tube dia from 20A, 25A, 32A, 40A, and 50A.